

RELEASE NOTES: LXEdge v 1.1.1.32

Released: May 15, 2024

Major Updates

- Allow question text to be edited in between charts within a series. Edits will be used in subsequent charts run in the series.
- Remove ability to remove charts within a PF that have not been run.
- Chart creation
 - Adjust so the time-axis scaling matches paper charts (0.5" / 5 seconds)
 - Do not allow zooming of the time axis
 - Do not allow panning of the time axis
- Chart review
 - Open chart to the standard time-axis scaling
 - Allow scroll-wheel zooming of time-axis
 - Allow time axis to be panned
 - Clicking on a question centers that question in the view.
- Chart replay
 - Made it so that questions now advance automatically during replay.
- Audio/Video Settings
 - Added ability to select audio quality for microphones. Resolved issue that audio file sizes were very large.
 - Cameras and microphones now keep their settings after being unplugged and plugged back in.
 - When plugged in, cameras and microphones appear without needing to navigate away and back to the settings.
 - Added ability to delete a previously added Network Camera.
 - Modified the resolution for the "Medium" video setting.

Minor Updates

- Settings
 - Made it clearer that the top item in Data Stripping settings enables/disables stripping completely.

RELEASE NOTES: LXEdge v 1.1.1.32

- Changed the minimum allowed Question Timer setting from 18 seconds to 0 seconds.
- Removed the “Display Grid at 5 Second Divisions” setting.
- Removed the “Use Application Settings” setting.
- Removed the “Maximum Data Display Rate (Hz)” setting.
- While running a chart, repeated questions will show in the question bar.
- While running a chart, when a question is completed, the program will move to the first unasked question.
- Adjust default sensor vertical positions to match positions for a typical examiner.
- Added button to show the “Release Notes” on the web.
- Do not allow user to close LXEdge while running a chart.
- Now disables “Center All” button while running a chart.
- On the question template editor, ensure that the question boxes in the sequences are always wide enough to contain the entire Question ID.
- Prevent LXCAT users from selecting a different question set or modifying questions while inside PF.
- Hotkeys
 - “F10” now appears instead of “System” for the hotkey associated with Unexpected Behavior.
 - Ignore “Ctrl” key when setting hotkeys.
 - Removed the “Question Completion” and “Question Set Editor” hotkeys.
- Removed the Save button from the Personal History and Series entry views.
- Converted the Default PF template to the new PF format.
- Changes to Preview PF template view
 - Show the name of the selected Personal History.
 - Added Scoresheet and Report.
 - Standardized font and margin.

Bug Fixes

- Largely eliminated sluggish behavior that could occur after extended usage of LXEdge.
- Resolved issue that taking a picture with the LXEdge Recorder would mark the current tab complete, even if it was not the Photo tab.
- Resolved issue in Question Template selector that clicking “New Folder” repeatedly would appear to create multiple folders called “New Folder”.
- Resolved issue that search function didn’t work for question set templates.
- Resolved issue that under certain scenarios, chart/media playback would revert to beginning instead of continuing from current spot.
- Resolved issue that prevented LXEdge from updating the firmware on older LX6 hardware. This prevented usage of that hardware with LXEdge.
- Resolved issue that prevented old LXCAT PF’s from being loaded.
- Resolved issue that pressing “Alt” key would impute an annotation on the chart.
- Edits to the last edited field in Personal History could be lost when navigating to Series.

RELEASE NOTES: LXEdge v 1.1.1.32

- Related to PF Template
 - Resolved issue that following certain steps, changes to a PF template would not be reflected in a PF immediately created from the template.
 - Resolved issue that a message related to missing question set would be incorrectly shown when creating PF from PF template that included a question set from a folder.
 - Resolved issue that PF created from edited Default PF template would not contain Scoresheet or Report.
 - Resolved issues that series could be numbered out of order following deletion or reordering.
- Resolved issue that the Annotation (F1-F12) hotkeys would be ignored under a very specific situation.

Known Issues

- While running a chart, a slight jump sometimes occurs at question onset or offset, response, and selecting another question.
- The ESS Scoresheet Auto Select function is not working as examiners would expect it to. We will be adjusting the drop-down menus in the future to Scoring Types: ESS, 3-position, 7-position; Exam Type: Single-Issue (Non-Independent), Multiple-Issue (Independent); Decision Rules: Two Stage Rules, Subtotal Score Rules, Federal Zone Rules, Grand Total Rules. Examiners should manually select the correct Scoring Type and Decision Rules in the meantime.