

RELEASE NOTES: LXEdge v 1.1.2.72

Released: August 21, 2024

Major Updates

- Update Charting package to latest version
- Overhaul of AV and Chart recording and playback to resolve significant issues
- Add ability to import NCCA ASCII files
- Combining Charts
 - Allow users to combine multiple charts within a PF for cross reference and comparison
 - Applies to multiple charts in either the same or different series
 - Combined charts are shown in a separate window for navigation
 - Each chart in the Combined Charts view has a separator for easier distinction between charts
 - Chart questions are marked at the bottom of the Combined Charts view
- Chart Zoom
 - Display current zoom level while viewing a chart
 - Allow for a quick/easy return to 100% zoom level after zooming in or out
- ESS Report Updates
 - ESS Reports now require a new field, “Exam Type” which specifies either a Single Issue or Multiple Issue exam
 - The “Decision Rule” dropdown has been updated, now allowing only Grand Total Rule, Two Stage Rule, Subtotal Score Rule, and Federal Zone Rule as selection options
 - Both “Exam Type” and “Decision Rule” must be selected before the ability to create an ESS Report is allowed
 - “Decision Rule” can no longer be found in the Settings and can only be accessed when updating scoresheets

Minor Updates

- Chart questions can now be navigated using keyboard arrows
- Removed the “Reset” button at the top of the chart
- When opening a PF from a .lxw file, the PF is no longer moved to “My LXEdge” folder
- PFs will be locked when opened from an “Upload Without Stripping” file
- Gray vertical line no longer appears on chart when Center All is selected
- Removed “To Live” button from the top of charts during recording

RELEASE NOTES: LXEdge v 1.1.2

- Moved the “Speak Text” buttons that are shown when editing Question Sets
 - Previously shown after the “Media File” field and is now located between the “Text” and “Expected Response” columns
- Allow limited editing of questions between charts in a series
- Streamlined Question Set Template editing process
 - The “Type” field can no longer be changed after it has been selected in Question Set creation
 - Similarly, the “Type” field is no longer accessible when editing a Question Set Template
- Allow for trace movement independent of the trace arrow
 - This can be achieved by hovering over a trace arrow with the mouse, holding Ctrl + scrolling the mouse wheel
- Multiple file attachments can be uploaded at the same time to a PF
- Allow for greater precision when adjusting the gain at smaller amounts
- Add option to store spoken text to speech to files
- Advancing to a question in scoresheet now centers that question on the chart
- Remove “Use Alternative Fill Source” setting as it is no longer necessary after update to Charting package

Bug Fixes

- Resolve many issues with AV and chart playback
- Traces can no longer be dragged below the bottom of the chart view
- Fixed some instances where the X-Axis Visible Range of a chart displayed incorrectly
- Fixed a default answer in Utah CQT 3RQ Question Template
 - Previously, the Expected Answer to the Sacrifice Relevant question in this template was set to “No” when it should have been “Yes”
- Fixed chart jitter when onsetting or offsetting questions
- NCCA Export improvements
 - NCCA Export folder location has been fixed to be directly under the PF folder
 - NCCA output file names have been fixed to properly number each chart uniquely by series and chart number
- Fixed instances where the Add Question button wasn’t working for a newly created Question Set
- Resolve issues with playback of videos using a specific audio codec by converting the videos before playback