

## RELEASE NOTES: LXEdge Version 1.1.4.31

Released: November 1, 2024

### Major Updates

- Added Spanish language support
- Related to scoring and scoresheet
  - Add setting of which scorer (Examiner, Reviewer, Reviewer Two) should be selected when scoring a PF for first time
  - While within PF, always return to most recently selected scorer
  - Shorten scorer labels to save space
  - While reviewing chart, selecting question at bottom of chart now updates selected question in scoresheet
  - Add button to show/hide the scoresheet inside the chart; the scoresheet will no longer be translucent
  - Hide the “Show Report” button in the Compare Scoresheets view

### Minor Updates

- Limit number of characters in question labels to 8
- Remove the “Audit Log” tab
- Refinements to appearance and behavior related to selecting and editing templates
- Add vertical scrollbar to About page
- Make it easier to activate tooltips associated with tab items in left menu
- Remove Cardio Thumb sensor from LXEdge
- Remove redundant toggles to enable/disable that appear at top of sensor settings
- Hide the option to combine charts until some issues have been resolved

### Bug Fixes

- Line length traces would not appear while previewing or recording chart
- Re-enable PF integrity checks that verify that charts have not been swapped or removed
- Selecting a question near the end could adjust zoom while reviewing chart
- Extra blank window would appear when starting LXEdge or LX Recorder in Windows 10
- When adding item to template, unexpected behavior could occur when clicking “Close” without selecting item
- When submitting an item to Contact Support, double submission would occasionally occur

