

RELEASE NOTES: LXEdge Version 1.1.5.66

Released: January 15, 2025

Major Updates

- PF Tools tab has been added
 - PFs can be copied or moved to alternate location
 - PFs can be deleted and emailed
 - PFs can be archived into a zip file and restored from said format
 - Data stripping options have been clarified and are now located on this tab instead of in system settings
- Voices available in the “Time & language -> Speech” settings in Windows settings can now be used for speech synthesis in LXEdge
- Video recorded outside of chart times can now be reviewed in a Multimedia reviewer window inside LXEdge
- Behind-the-scenes overhaul of chart-related code

Minor Updates

- Chart Info tab now provides more information
 - Starting/Stopping Cardio cuff pressure
 - Starting/Stopping/Average EDA resistance
 - Chart end time
- Re-enable ability to combine charts
- Allow editing of Personal History and Series information unless PF has been locked. Editing was previously prevented once a chart had been run.
- Data stripping options are now available when emailing/archiving within a PF
- Prevent annotations from being added outside of chart runtime
- Language setting has been moved to Settings -> System
- Bulk import of LXSoftware Question Sets now maintains the imported folder structure
- Improved functionality of use of question set templates imported from LXSoftware
- Add more details to error messages related to Upload button and opening charts
- When opening a chart for review, select the first Relevant Question
- All Series can now be expanded at once with the “Expand All” button
- Archived PFs are no longer locked



RELEASE NOTES: LXEdge v 1.1.5.66

- For Acquaintance tests, add “Key” to list of valid question IDs
- Removed “Prompt to start recording at chart start” setting

Bug Fixes

- Resolve issue that software could crash when opening blank question set within PF
- Resolve issue that PF created from a blank PF template would not open correctly
- Resolve issue that “Open Folder” button on attachments tab would open incorrect folder when nothing had been attached
- Resolve some issues related to chart playback and recording
- Resolve issue that chart preview would appear when clicking on chart tab immediately after creating/opening a PF
- Data Stripping issues have been resolved
- Resolve crash that could occur when dragging items in Series Template editor
- Spanish translation of certain strings has been fixed
- Resolve issue that Chart tab would be highlighted when opening a template for editing
- Resolve some issues related to filtering templates
- Resolve issues with sequence navigation that could occur when one or more sequences within the question set had been deleted
- Errors when attempting to navigate from a running chart have been resolved
- Errors when using Change button while in Template editor have been resolved
- Fixed issues related to usages of Upload button when PF contains media files
- Resolve issue that expected voice might not be used when testing speech synthesis inside question set editor
- Resolve issue that “Stopping A/V Recording” would always appear when navigating to Home Page, even when recording was not in progress