

RELEASE NOTES: LXEdge Version 1.1.5.70

Released: February 4, 2025

Major Updates

- Changes related to “LXEdge Directory” setting
 - Setting now applies to all users of a computer instead of just the current user.
 - Default is still set to user’s “Documents” folder, but LXEdge now properly accounts for file migration if user later enables OneDrive.
 - Setting can now only be changed using the folder-selection dialogue.

Minor Updates

- Deleted PFs and templates are now placed in Recycle Bin instead of being completely removed from computer.
- Added file association between PF template (.lxw) and LXEdge. This allows double-clicking on the .lxw file inside a PF to open the PF in LXEdge.
- Simplify steps for creating Archive in PF Tools by removing “Destination Location” textbox. Minor changes to text on PF tools.
- Clear search button (blue “X”) is always shown in the Search bar.

Bug Fixes

- Resolve issue that “LXEdge Directory” setting would revert to default value when installing a new version of LXEdge.
- Resolve issue that enabling OneDrive could make it appear like templates and PFs were missing.
- Resolve issue that playback of text-to-speech in charts with Speech Synthesis “Record to file” setting enabled would fail.
- Resolve issue that running charts out of order would lead to inability to open charts because of chart internal inconsistency error.
- Resolve issues related to combining charts:
 - When combining charts created in earlier versions of LXEdge, the labels for all charts would be “Series 0”.
 - Rarely, traces could appear unusual near beginning of a chart. This was primarily an issue with charts recorded using simulator data.

RELEASE NOTES: LXEdge v 1.1.5.70

- Resolve issues related to templates:
 - When using the “Change” buttons while editing a PF Template, the information displayed would not update as expected.
 - On Home Page, amount of information displayed in PF Template preview could change when navigating to different tab and back.
 - Template list was not being updated as expected when deleting or renaming a template.
- Resolve issues related to template search:
 - Search would not clear when navigating from one template tab to another. This could make it appear that templates were missing.
 - Search would not work as expected after clearing a search that had only shown a single result
- Resolve unexpected confirm dialogue and potential crash when deleting PF internally from the Navigation bar.